



LEGEND:

- ① ECO-MAT PER PLAN
- ② ECO-INDICATOR ON SWING ARM
- ③ PVC TO DRIP LINE TUBING CONNECTION (PLD OR PLD-LOC FITTINGS) TYP.
- ④ AIR RELIEF VALVE IN VALVE BOX
- ⑤ PVC EXHAUST HEADER - SIZE PER PLAN
- ⑥ ECO-WRAP PER PLAN
- ⑦ TREE (SEE PLANTING PLAN)
- ⑧ CUT MAT AS NECESSARY
- ⑨ PLD OR PLD-LOC FITTINGS TYP.
- ⑩ ECO-WRAP TO CONNECT ECO-MAT
- ⑪ FLUSH POINT (PLD-BV) IN SUBTERRANEAN BOX PER PLAN
- ⑫ PVC SUPPLY HEADER - SIZE PER PLAN
- ⑬ DRIP CONTROL ZONE KIT PER PLAN (TYP.)

NOTES

AIR RELIEF VALVE (PLD-AVR) INSTALLED IN VALVE BOX AT OPTIMAL HIGHEST POINT FROM CONTROL ZONE KIT. MULTIPLE AIR RELIEF VALVES MAY BE NEEDED TO ACCOMMODATE DIFFERENCES IN GRADE.

ECO-INDICATOR TO BE INSTALLED AT OPTIMAL FURTHEST POINT FROM CONTROL ZONE KIT IN CLEAR VIEW WHEN POPPED UP.

FLUSH POINT TO BE INSTALLED AT OPTIMAL FURTHEST POINT FROM CONTROL ZONE KIT TO ALLOW FOR MAXIMUM DEBRIS FLUSH IN SYSTEM.



ECO-MAT AROUND TREE WITH ECO-WRAP SINGLE TREE RING SEPARATE ZONE

Hunter HM.EM.11

NOT TO SCALE