



LEGEND:

- ① ECO-MAT PER PLAN
- ② FLUSH POINT (PLD-BV) IN SUBTERRANEAN BOX PER PLAN
- ③ PLD OR PLD-LOC FITTINGS TYP.
- ④ AIR RELIEF VALVE IN VALVE BOX
- ⑤ PLD BLANK TUBING EXHAUST HEADER
- ⑥ ECO-INDICATOR ON SWING ARM
- ⑦ PLD BLANK TUBING SUPPLY HEADER
- ⑧ DRIP CONTROL ZONE KIT PER PLAN

NOTES

AIR RELIEF VALVE (PLD-AVR) INSTALLED IN VALVE BOX AT OPTIMAL HIGHEST POINT FROM CONTROL ZONE KIT. MULTIPLE AIR RELIEF VALVES MAY BE NEEDED TO ACCOMMODATE DIFFERENCES IN GRADE.

ECO-INDICATOR TO BE INSTALLED AT OPTIMAL FURTHEST POINT FROM CONTROL ZONE KIT IN CLEAR VIEW WHEN POPPED UP.

FLUSH POINT TO BE INSTALLED AT OPTIMAL FURTHEST POINT FROM CONTROL ZONE KIT TO ALLOW FOR MAXIMUM DEBRIS FLUSH IN SYSTEM.



ECO-MAT - PLAN VIEW WITH BLANK PLD HEADER AND EXHAUST AT MAT GRADE CENTER FEED

Hunter HM.EM.22

NOT TO SCALE