

**Feature****Where Found****PROGRAMMABLE  
SENSOR OVERRIDE**Hold **-**, turn to Start Times**CYCLE AND SOAK**Hold **+**, turn to Run Times  
Press **PRG** to set Soak**DELAY BETWEEN  
STATIONS**Hold **-**, turn to Run Times**HIDE PROGRAMS**Hold **-**, turn to Water Days**SOLAR SYNC DELAY**Hold **+**, turn to Solar Sync**CLIK DELAY**Hold **+**, turn to System Off

## Feature

## Where Found

**TOTAL RUN TIME**

Turn to Run Times  
Press ◀ from Station 1 to view

**TEST PROGRAM**

Hold **PRG** for 3 seconds

**EASY RETRIEVE™**

Press + and **PRG** to Save  
Press - and **PRG** to Restore

**TOTAL RESET**

Press **PRG** and **RESET** button

**QUICK CHECK™**

Press + -, ◀, ▶ together  
Press + to begin check

**RUN PROGRAM**

Hold ▶, press **PRG** to select