



LEGEND:

- ① ECO-MAT PER PLAN - CUT MAT TO FIT LIMITS OF PLANTED AREA
- ② DRIP CONTROL ZONE KIT PER PLAN
- ③ PVC TO DRIP LINE TUBING CONNECTION (PLD OR PLD-LOC FITTINGS) TYP.
- ④ ECO-WRAP CONNECTIONS
- ⑤ PVC SUPPLY HEADER - SIZE PER PLAN
- ⑥ PLD OR PLD-LOCK FITTING (TYP.)
- ⑦ ECO-INDICATOR ON SWING ARM
- ⑧ AIR RELIEF VALVE IN VALVE BOX
- ⑨ FLUSH POINT (PLD-BV) IN SUBTERRANEAN BOX PER PLAN

NOTES
 AIR RELIEF VALVE (PLD-AVR) INSTALLED IN VALVE BOX AT OPTIMAL HIGHEST POINT FROM CONTROL ZONE KIT. MULTIPLE AIR RELIEF VALVES MAY BE NEEDED TO ACCOMMODATE DIFFERENCES IN GRADE.

ECO-INDICATOR TO BE INSTALLED AT OPTIMAL FURTHEST POINT FROM CONTROL ZONE KIT IN CLEAR VIEW WHEN POPPED UP.

FLUSH POINT TO BE INSTALLED AT OPTIMAL FURTHEST POINT FROM CONTROL ZONE KIT TO ALLOW FOR MAXIMUM DEBRIS FLUSH IN SYSTEM.